

Requirements for a chemical for cleaning equipment and pipelines.

The chemical is supposed to be used during the steaming of equipment and pipelines.

For steaming, steam is used with a pressure of up to 10 bar and a temperature of up to 200 degrees Celsius.

Chemical requirements:

1. Deactivation of pyrophoric compounds.
2. Deactivation of hydrogen sulfide.
3. Deactivating LEL
4. Deactivation of benzene.
5. Removal of deposits of heavy hydrocarbons and coke.
6. Reducing the time of steaming equipment and pipelines.
7. The chemical should not be corrosive to equipment.